


PAROS

LUXO|Outdoors

Paros 8-Seater Outdoor Dining Set



Assembly requires at least 2 persons


PLEASE USE ALLEN KEY PROVIDED TO ASSEMBLE THE PRODUCT. DO NOT USE POWER TOOLS.



THANK YOU FOR YOUR PURCHASE!


We hope you enjoy this product as much as we enjoyed making it!

We suggest you spend **35 minutes** in reading these tips before assembling the unit. Strictly follow the instructions step by step.




Tool Check

Check contents to ensure that you have the specified quantity for all identified parts and metal fittings.




Safety Check

Keep children and pets away from working area as unit has small parts that are choking hazards if swallowed.



Do Not Use Power Tool

Do not use any power tool for assembly as it may damage the unit and make it unsafe to use. Use of any power tool will invalidate any claim you may have.



Easier Assembly Tip

We strongly advise that all fittings be finger-tightened during the initial assembly phase. You may fully tighten them all once assembly is complete.

HARDWARE LIST

Please check if you have all the fittings and tools listed below.

A



M6x15mm BOLT
23 PCS

B



M6x35mm BOLT
22 PCS

C




WASHER
45 PCS

D




M6 ALLEN KEY
1 PC




PARTS LIST




1 x1




4 x1




7 x1



10 x6



13 x4



16 x1




2 x1



5 x2




8 x1



11 x6



14 x1



17 x1




3 x1




6 x1




9 x1



12 x1




15 x1



18 x1


STEP 1

YOU WILL NEED		
B		x4
C		x4
D		x1



STEP 2


YOU WILL NEED		
B		x3
C		x3
D		x1



ASSEMBLY STEPS


STEP 3

YOU WILL NEED		
B		x4
C		x4
D		x1



STEP 4


YOU WILL NEED		
A		x2
C		x2
D		x1



ASSEMBLY STEPS


STEP 5

YOU WILL NEED		
B		x4
C		x4
D		x1



STEP 6


YOU WILL NEED		
B		x3
C		x3
D		x1



ASSEMBLY STEPS


STEP 7

YOU WILL NEED		
A		x3
C		x3
D		x1



STEP 8


YOU WILL NEED		
A		x2
C		x2
D		x1



ASSEMBLY STEPS


STEP 9

YOU WILL NEED		
B		x4
C		x4
D		x1



Note: The middle leg of the chair is a functional design added for structural support. It is intentionally designed to not touch the floor at the start. It provides support for the chair over time to prevent it from wobbling, especially with regular use.


STEP 10




ASSEMBLY STEPS

STEP 11

YOU WILL NEED		
A		x12
C		x12
D		x1




STEP 12




ASSEMBLY STEPS

STEP 13

YOU WILL NEED		
A		x4
C		x4
D		x1




STEP 14



ASSEMBLY STEPS


STEP 15



Coffee table to dining table mode:

Two people stand on either side along the width.

Lift slowly together to the uppermost position, shift slightly to the right, then lower gently to engage into the locating slots.



Dining table to coffee table mode:



Two people stand on either side along the width.

Lift slowly a short distance to the uppermost position, shift slightly to the left to disengage from the locating slots, then lower gently to the bottom position.

ASSEMBLY STEPS

GREAT JOB. YOU'RE DONE!

To move the assembled units, please lift it up and do not drag to avoid damaging the floor or breaking the parts.



When you assemble this set please make sure all screws are fastened tightly. After one or two months, please make sure all screws are still tight.



Before using this set, please check if the metal support legs under the them are in an upright position. Ensure that they are always in an upright position.



Our 3-seater sofa can hold weight of up to 360kg, the bench can hold weight of up to 120kg, and our raising table can hold weight of up to 75kg. We don't suggest overloading them beyond their weight capacity.

CARE INSTRUCTION

Follow these basic steps to protect your furniture.

Aluminium Furniture

Clean aluminium frames with a soft cloth and mild soapy water. Avoid abrasive cleaners or brushes to prevent surface scratches. During extreme weather, cover or store furniture indoors.

Temperature and Humidity

For product longevity, avoid prolonged exposure to direct sunlight.

Cushions

Regularly brush off dirt and debris with a soft-bristle brush. Spot clean stains promptly with a mild detergent and water solution. Cushion covers have zippers and are machine washable. Ensure cushions are fully air-dried to prevent mould & mildew growth before using or storing.

Avoid Excessive Weight

Don't overload the set beyond its weight capacity.

***Again, we thank you for your purchase.
You've made our day, and we hope you have a great one too!
Enjoy your outdoor furniture!***

For any questions, please call us at 02 8999 1114 or contact our online customer service team through our website.

LUXO|Outdoors