


Anders

LUXO|Furniture

180cm Oval Wooden Dining Table



Assembly requires at least 2 people



Additional tools you may need


We recommend the use of a power drill on a low-speed setting for quick assembly.



ASSEMBLY INSTRUCTIONS


THANK YOU FOR YOUR PURCHASE!

We hope you enjoy this product as much as we enjoyed making it! We suggest you spend **5 minutes** in reading these tips before assembling the unit. Strictly follow the instructions step by step.




Tool Check

Check contents to ensure that you have the specified quantity for all identified parts and metal fittings.




Safety Check

Keep children and pets away from working area as unit has small parts that are choking hazards if swallowed.



Use of Power Tool

We recommend the use of a power drill on a low-speed setting for quick assembly.




Easier Assembly Tip

We strongly advise that all fittings be finger-tightened during the initial assembly phase. You may fully tighten them all once assembly is complete.

HARDWARE LIST

Please check if you have all the fittings and tools listed below.

A



SCREW $\varphi 8 \times 30$
10 pcs

B




ALLEN KEY #5
1 pc


C




FOOT PAD $\varphi 30$
12 pcs




PARTS LIST



1 x1




2 x1




3 x1

STEP 1



YOU WILL NEED		
B		x1


STEP 2



YOU WILL NEED		
C		x12

ASSEMBLY STEPS


STEP 3



YOU WILL NEED

A		x4
B		x1

STEP 4





YOU WILL NEED

A		x6
B		x1


ASSEMBLY STEPS

GREAT JOB. YOU'RE DONE!

To move the assembled unit, please lift it up and do not drag to avoid damaging the middle part.



When you assemble this dining table, please make sure all screws are fastened tightly. After one or two months, please recheck and make sure all screws are still tight.



The top of this dining table can hold up to 200kg.

CARE INSTRUCTION

Follow these basic steps to protect your furniture.

Clean Gently

Use a mild wood cleaner or a mixture of water and mild dish soap to clean spills. Wipe the surface gently with a damp cloth, then dry it thoroughly.

Temperature and Humidity

Avoid direct sunlight. Maintain a consistent room temperature and humidity level to prevent wood from warping or cracking.

Use Furniture Pads

Place furniture pads or felt protectors under furniture legs to prevent scratches on floors.

Avoid Excessive Weight

Don't overload drawers or surfaces beyond their weight capacity.

***Again, we thank you for your purchase.
You've made our day, and we hope you have a great one too!
Enjoy our product!***

For any questions, please call us at 02 8999 1114 or contact our online customer service team through our website.

LUXO|Furniture