







LUXO | furniture


Assembly Instructions

Marshall 180 cm Floating Entertainment Unit with LED




Tools needed to assemble (Drill required)
1x screwdriver or hand-held electric drill &hammer .

	 Ø8*40	 LED		
A*20	B*16	C*1	D*1	E*1
			 M3.5*14	 M3.5*30
F*3	G*6	H*4	I*34	J*6
	 Ø20	 M3*12		
K*8	L*20	M*4	N*1	O*2


①
④
⑨
③
⑨
⑤
⑥
⑧
②
⑥
⑦


1

Please remove the double-sided adhesive tape and glue the led lgiht to the cabinet firstly , then Fixed clamp




TOOL		
A1		6
C	LED	1
M	M3*12	4


2




TOOL		
A1		4
B	Ø8*40	8


3




TOOL		
A1		2
B	 Ø8*40	8

4





TOOL	
A2	 6

5




6






TOOL		
A2		6
D		1
E		1

7




TOOL		
I	M3.5*14	8
K		8

8




TOOL		
H		4
I	M3.5*14	8

9




TOOL		
I	M3.5*14	16

10




TOOL		
A1		8


11




TOOL		
A2		8
I	M3.5*14	2
L	Ø20	20
N		1

12










TOOL		
F		3
G		6
J	M3.5*30	6

13








After finishing Assembling
please make sure peel off the
protective film on the board .

TOOL		
O		2

LED Light

If the lights are not working properly, please check the following:

1. Please make sure the connections are properly connected, please refer to the image below.
2. Please check the remote control sensor cover, pull out the plastic cover.
3. Don't use the remote too far from the receiver, make sure you have a clear line of sight.



Please buy the AAA battery for the remote control before use it ,Thanks .

Care instruction :Not under the blazing sun/
No Soak in water